

EuroAir – Washing Instructions

Trevira CS, DFC Material, Anti-Static & Std. Polyester

- Machine wash is okay.
- The machine should only be half full.
- Wash at 20 – 40 °C with ordinary detergent until the washing water is quite clean in intervals at 5 – 15 min at a time. *(If the ducts are very dirty the washing water should be rinsed between washes)*
- After washing the ducts should be flushed with cooled clean water.
- If needed before the second last flush a disinfectant (*Chlorine*) can be added if needed. *(Colored ducts can lose some of their color when disinfected)*
- Do not add fabric softener.
- When drying it is preferred that the ducts drip dry, they may also by ordinary centrifugation *(At low speed)* or by allowing the ducts hanging on a line while still moist.
- The ducts can be tumble-dried if the exit temperature air not exceed 60 °C. *(Tumble-drying the ducts may lead to a small shrinkage of the ducts).*

Injekt Light

- The Injekt Light Material ducts do not require a cleaning from a flow technical point of view, however aesthetics or hygiene conditions may necessitate the cleaning of the ducts. *(The Injekt Light ducts are made with a dirt repellent plastic coating making it easier to maintain)*
- The best way of cleaning the Injekt Light material ducts is using a moist damp cloth on the outside. *(Standard washing detergent can be used similar to products used for floors, tables etc.).*
- After cleaning the ducts should be wiped down using clean water.
- If the duct inside of the Injekt Light ducts is very dirty the ducts should be turned inside out and swept, blown with air or vacuumed *(carefully)*.
- Use of Hydrocarbon based or solvents containing chlorine must not be used under any circumstances.
- It is possible to machine wash an Injekt Light duct however it can afterwards become wrinkled and lose some of its aesthetical appearance. *(If it needs to be machine washed the machine should only be filled up 1/3 with a max temperature of 30°C and using a fine wash washing program)*

Cleanroom

- It is not recommend cleaning under normal circumstances.
- It is however possible to follow the procedure given under Trevira CS, DFC Material, Anti-Static & Std. Polyester. *(During washing particles can be picked up by the fabric and later be blown into the room).*
- If cleaned the given EuroAir guarantee will no longer be valid.
- If the ducts turn slightly grey during operation the pre-filter should be examined and possibly exchanged.

M0

- It is not recommend cleaning under normal circumstances.
- Do not machine wash.
- Might be cleaned with a damp cloth applied to a thin solution of soapy water.
- Must be dried with clean water and allowed to drip dry.

Nomex

- It is not recommend cleaning under normal circumstances.